

RIGGIES® GUNWALE MOUNT INSTALLATION INSTRUCTIONS AND USER GUIDE



INSTALLATION INSTRUCTIONS

Attach ① to gunwale and ② to halyard circuit.

HOW TO ADJUST TENSION

Look closely at ③, notice how ④ passes thru it, creating both upper and lower exit points. To increase tension, firmly hold ③ and while holding ④ near the lower exit point, slowly pull down towards the boat. To decrease tension, firmly hold ③ and while holding ④ near the upper exit point, slowly pull up and away from the boat.